

PRODUCT DATASHEET

OUTLINE GUIDELINES FOR USING KINGDRYMIX RENDERS

PREPARATION

Ensure there is a sufficient key in the substrate – prepare as required

Wet it to check absorption – prepare to control the suction as required

MIXING THE MATERIAL

- Store the bags off the ground in dry conditions
- Add between 3 to 4 litres of water per bag, keep this constant
- Do not over water / overmix
- Mix for at least 5-10 minutes in a mechanical mixer / paddle mixer

APPLYING THE MATERIAL

- Moisten the surface if required
- Apply passes evenly
- Do not apply unless the temperature is 3 degrees and rising
- Do not apply in the rain or direct sunlight
- Protect the render after/during application

TROUBLESHOOTING

The render is difficult to work with	lack of water use optimum amount, not mixed sufficiently
Not enough open time	lack of water substrate too absorbent, seek advice
Goes “off” too quickly	lack of water – dehydrated, high suction from substrate
Lime bloom or patching evident	mortar not protected after/during application